

Colligo Torsion Line Clamp Installation Instructions

Applicable to part numbers RC9-11, RC12-13, RC 14-15.

Installation Sequence

1. Install clamp halves with 4 clamp screws. Be sure to set the clamp such that it is as close to possible to the line terminator. This will prevent the line terminator from getting too loose as the line comes under tension.
2. Use provided nail and tap lightly into each line screw hole approximately 5 mm depth. Be careful not to damage the threads.
3. Then start all 12 line screws for 2 turns. **Do not drive any screws completely in until all 12 screws are started.**
4. Next, Drive all 12 line screws until each screw head is seated in clamp.

**Be very careful when driving the line screws in, too much torque will break the screw heads off. Using a power screw driver is not recommended.

